


Accessories



NOTE: The Sure Cross® radio installation shown includes wireless accessories available from Banner. It is for illustration purposes only. Installations may vary.

(1) Enclosures	511
(2) Antennas	533
(3) Antenna Cables.....	534
(4) Surge Supressors.....	535
(5) Power Supplies	535
(6) Brackets	537
Cables	538
Cordsets.....	539
Hardware and Replacement Parts.....	541
Replacement Filters	541
Cable Glands and Plugs.....	542
Metal Housing Accessories	542

(2) Antennas, continued



Omni-Directional Fiberglass Antennas with N-Type Female Connections

BWA-9O6-A	900 MHz	2 dBi, Rubber swivel (ships with 900 MHz radios)
BWA-2O8-A	2.4 GHz	8.5 dBi, Fiberglass, 24 in
BWA-2O6-A		6 dBi, Fiberglass, 16 in (shown)
BWA-9O6-AS	900 MHz	6 dBi, Fiberglass, 1/4 Wave, 23.6 in (1.3 inch diameter)
BWA-9O8-AS		8 dBi, Fiberglass, 3/4 Wave, 63 in (1.5 inch diameter)



Directional (Yagi) Antennas with N-Type Female Connection

BWA-9Y6-A	900 MHz	6.5 dBd, 6.8 × 13 inches Outdoor
BWA-9Y10-A	900 MHz	10 dBd, 6.8 × 24 inches Outdoor

(3) Antenna Cables



Antenna Cables: RP-SMA to RP-SMA

BWC-1MRSFRSB0.2	RG58, RP-SMA Male to RP-SMA Female Bulkhead, 0.2 m
BWC-1MRSFRSB1	RG58, RP-SMA Male to RP-SMA Female Bulkhead, 1 m
BWC-1MRSFRSB2	RG58, RP-SMA Male to RP-SMA Female Bulkhead, 2 m
BWC-1MRSFRSB4	RG58, RP-SMA Male to RP-SMA Female Bulkhead, 4 m
BWC-2MRSFRS3	LMR200, RP-SMA Male to RP-SMA Female, 3 m
BWC-2MRSFRS6	LMR200, RP-SMA Male to RP-SMA Female, 6 m
BWC-2MRSFRS9	LMR200, RP-SMA Male to RP-SMA Female, 9 m
BWC-2MRSFRS12	LMR200, RP-SMA Male to RP-SMA Female, 12 m



Antenna Cables: RP-SMA to N-Type

BWC-1MRSMN05	LMR100 RP-SMA to N-Type Male, 0.5 m
BWC-1MRSMN2	LMR100 RP-SMA to N-Type Male, 2 m



Antenna Cables: N-Type

BWC-4MNFN3	LMR400 N-Type Male to N-Type Female, 3 m
BWC-4MNFN6	LMR400 N-Type Male to N-Type Female, 6 m
BWC-4MNFN15	LMR400 N-Type Male to N-Type Female, 15 m
BWC-4MNFN30	LMR400 N-Type Male to N-Type Female, 30 m