

Heavy-Duty Air Circulators

Component Parts / Accessories for Assembled Fan Heads




Adjustable Pedestal

EDP No.	Catalog No.	Ship Wt.	Description
21152	8CP2B	13	5' to 8' pedestal (fits all Heavy Duty fans)

Floor Base



EDP No.	Catalog No.	Ship Wt.	Description
21165	A786B-1	17	For use with 18" & 20" oscillating & non-oscillating fans with 21152 pedestal
21166	A786B-2	34	For use with 24" & 30" oscillating & non-oscillating fans with 21152 pedestal



Wall Bracket



I-Beam Bracket

Brackets

EDP No.	Catalog No.	Bracket Type	Ship Wt.	Description
21187	878W	Wall	10	15° Tilt Built In. Use for HD air circulator wall mountings, Includes Safety Cable Kit
21191	700-U	I-Beam	14	Use for HD air circulator I-Beam mountings, Includes Safety Cable Kit
21203	CK-2	Vertical	5	Use for HD air circulator vertical mount (non-oscillating only) Includes Safety Cable Kit. Extension Cord and Extension Pole Not Included.



Vertical Bracket



Safety Kit



Extension Cord



Wheel Kit

Accessories

EDP No.	Catalog No.	Ship Wt.	Description
21204	Safety Kit	1	12' of 1/16" diameter cable, two clamp and instructions. This safety cable kit is available for retrofit applications.
12002	DJ-EC-6	1	6' extension cord - for use with 642-AC2SDP Drop Cord Motor - Yellow
12008	DJ-EC-9	2	9' extension cord - for use with 642-AC2SDP Drop Cord Motor - Yellow
12009	DJ-EC-12	2	12' extension cord - for use with 642-AC2SDP Drop Cord Motor - Yellow
70601	AMFW30K	7	Snap on wheel kit with set screw lock for use on all floor model air circulators except I-2030 base. No tools required
01633	Cord	2	15' Supply Cord Replacement
01723	Switch	2	2 Speed / 3 Speed Pull Chain Switch

