

Accessories for 3RT contactors / 3RH control relays

Laterally mountable auxiliary switch blocks

Selection and ordering data



3RH2911-1DA02



3RH2911-2DA02

3RH19 21-1EA..
-1KA..

3RH2921-1DA02

For contactors/ control relays	Rated operational Current ⁴⁾ 6A NEMA A600/Q600	Contactor with HS block Ident. No.	Mountable to contactor/ contactor relay side	Auxiliary contacts		Screw Terminals ¹⁾	Spring Terminals ¹⁾
				Version			
						Order No.	Order No.
Type				NO	NC		

Laterally mountable auxiliary switch blocks according to EN 50012

Laterally mountable auxiliary switch block, 2-pole

Size S00 ^{1) 2)}

3RT201.	A600/Q600	12E	right or left	—	2	3RH2911-1DA02 3RH2911-1DA11	3RH2911-2DA02 3RH2911-2DA11
Ident. No. 10E	A600/Q600	21E	right or left	1	1		

Size S0 to S3

3RT2.2. ³⁾	A600/Q600	13E	right or left	—	2	3RH2921-1DA02 3RH2921-1DA11 3RH2921-1DA20	3RH2921-2DA02 3RH2921-2DA11 3RH2921-2DA20
Ident. No. 11E	A600/Q600	22E	right or left	1	1		
3RT2.3.	A600/Q600	31E	right or left	2	—		

First laterally mountable auxiliary switch block, 2-pole

Sizes S6 to S12

3RT1. 3 to 3RT1. 7	A600/Q600		right or left	1	1	3RH1921-1DA11	3RH1921-2DA11
--------------------	-----------	--	---------------	---	---	----------------------	----------------------

Second laterally mountable auxiliary switch block, 2-pole

Sizes S6 to S12

3RT1. 4 to 3RT1. 7	A300/Q300		right or left	1	1	3RH1921-1JA11	3RH1921-2JA11
--------------------	-----------	--	---------------	---	---	----------------------	----------------------

Laterally mountable auxiliary switch blocks according to EN 50005

First laterally mountable auxiliary switch block, 2-pole

Sizes S00 ^{1) 2)}

3RT2.1.	A600/Q600	02	right or left	—	2	3RH2911-1DA02 3RH2911-1DA11 3RH2911-1DA20	3RH2911-2DA02 3RH2911-2DA11 3RH2911-2DA20
Ident. No. 10E	A600/Q600	11	right or left	1	1		
	A600/Q600	20	right or left	2	—		

Sizes S0 to S3

3RT2.2., 3RT2.3. ³⁾	A600/Q600	02	right or left	—	2	3RH2921-1DA02 3RH2921-1DA11 3RH2921-1DA20	3RH2921-2DA02 3RH2921-2DA11 3RH2921-2DA20
	A600/Q600	11	right or left	1	1		
	A600/Q600	20	right or left	2	—		

Sizes S6 to S12

3RT1. 4 to 3RT1. 7	A300/Q300		right or left	—	2	3RH1921-1EA02 3RH1921-1EA11 3RH1921-1EA20	3RH1921-2EA02 — 3RH1921-2EA20
	A300/Q300		right or left	1	1		
	A300/Q300		right or left	2	—		

Second laterally mountable auxiliary switch block, 2-pole

Sizes S6 to S12

3RT1. 4 to 3RT1. 7	A300/Q300		right or left	—	2	3RH1921-1KA02 3RH1921-1KA11 3RH1921-1KA20	3RH1921-2KA02 — 3RH1921-2KA20
	A300/Q300		right or left	1	1		
	A300/Q300		right or left	2	—		

EN50005 and EN50012 designate the markings
of the auxiliary terminal numbers.

For position of the terminals see pages 2/202-2/206.

For int. circuit diagrams see pages 2/190-2/195.

1) With size S00, mounting according to EN 50012 is permitted only on basic units which have no NC contact integrated.

2) Ident. No. 41, 32 and 23 according to EN 50012 is also possible. Please note the corresponding circuit diagrams for mounting 3RH29 11-1DA.. on the left.

3) With 3RT23 2., 3RT25. 2. mountable only on the right.

4) UL ratings: See appendix page 19/7