

Power Contactors for Switching Motors

Accessories and Spare Parts for SIRIUS 3RT Contactors and SIRIUS 3RH2 Contactor Relays

General data


Version	For contactors 3RT2, sizes S00 to S3; 3RH2, size S00	3RT10, 3RT12, 3RT14; sizes S6 to S12	Selection and ordering data Page
Accessories for 3RT contactors and 3RH2 contactor relays (continued)			
Covers			
Terminal covers	3RT1946-4EA1, 3RT29.6-4EA.	3RT1956-4EA., 3RT1966-4EA., 3TX65.6-3B	3/118
Sealable covers	3RT2916-4MA10	3RT1926-4MA10	3/118
Miscellaneous accessories			
Base plates			
• For reversing contactor assemblies	--	3RT19.2-2A	3/119
• For contactor assemblies for star-delta (wye-delta) starting	3RA29.2-2F	3RA19.2-2.	3/119
Adapters for screw fixing	3RT1926-4P	--	3/119
EMC suppression modules	3RT2916-1P..	--	3/119
Additional load modules	3RT2916-1GA00	--	3/120
LED modules for displaying contactor operation	3RT2926-1QT00	3RT1926-1QT00	3/120
Control kit	3RT29.6-4MC00	--	3/120
Insulation stop for securely holding back the conductor insulation for conductors up to 1 mm²	3RT2916-4JA02	3RT1916-4JA02	3/121
Tools for opening spring-type terminals	3RA2908-1A	3RA2908-1A	3/121
Blank labels	3RT2900-1SB.0	3RT1900-1S..0	3/121
Spare parts for 3RT2 contactors			
Solenoid coils	3RT29...5...1	--	3/122, 3/123
Withdrawable coils	--	3RT19...5....	3/124
Contacts with fixing parts	3RT29...6.	3RT19...6.	3/125
Arc chambers	--	3RT19...7.	3/125

Power Contactors for Switching Motors

Accessories and Spare Parts for SIRIUS 3RT Contactors and SIRIUS 3RH2 Contactor Relays Accessories

Covers

Selection and ordering data

For con- tactors	Size	Version	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Type			d					
Terminal covers								
				Covers for contactors with screw terminals (box terminals) (2 units required per contactor)				
				• For 3-pole contactors				
		3RT203 S2	▶	3RT2936-4EA2		1	1 unit	41B
3RT2936-4EA2	3RT2946-4EA2	3RT204, 3RT244 S3	▶	3RT2946-4EA2		1	1 unit	41B
		3RT1.5 S6¹⁾	▶	3RT1956-4EA2		1	1 unit	41B
3RT1956-4EA2	3RT1966-4EA2	3RT1.6, 3RT1.7 S10¹⁾, S12¹⁾	2	3RT1966-4EA2		1	1 unit	41B
		3RT233, 3RT253 S2	5	3RT2936-4EA4		1	1 unit	41B
3RT2936-4EA4	3RT2946-4EA4	3RT234, 3RT254 S3	5	3RT2946-4EA4		1	1 unit	41B
				Covers for contactors with cable lugs and busbar connections				
				For complying with the phase clearances and as touch protection if box terminal is removed (2 units required per contactor)				
		3RT2.4 S3	5	3RT1946-4EA1		1	1 unit	41B
3RT1946-4EA1		3RT1.5 S6¹⁾	▶	3RT1956-4EA1		1	1 unit	41B
		3RT1.6, 3RT1.7 S10¹⁾, S12¹⁾	2	3RT1966-4EA1		1	1 unit	41B
3RT1956-4EA1	3RT1966-4EA1							
								
3RT1956-4EA4								
				• For the assembly kits for 3RA1953-... contactor assemblies for star-delta (wye-delta) starting (page 3/112) or for the 3RA1953-3... single-wiring modules (page 3/113)				
		3RT1.5 S6	2	3RT1956-4EA4		1	1 unit	41B
				Terminal covers with busbar connections				
				• Cover the three busbar connections, between the contactor and 3RB2 overload relay				
		3RT1.5 S6	▶	3RT1956-4EA3		1	1 unit	41B
3RT1956-4EA3	3RT1966-4EA3	3RT1.6, 3RT1.7 S10²⁾, S12²⁾	2	3RT1966-4EA3		1	1 unit	41B
		3RT1.5 S6	5	3TX6526-3B		1	1 unit	41B
3TX6526-3B	3TX6546-3B	3RT1.6, 3RT1.7 S10, S12	5	3TX6546-3B		1	1 unit	41B
Sealable covers								
		3RT2.1, 3RT2.2, 3RT2.3, 3RT2.4, 3RH2 ³⁾ S00 ... S3	2	3RT2916-4MA10		1	5 units	41B
3RT2916-4MA10	3RT1926-4MA10	3RT1.5 S6 ... S12	15	3RT1926-4MA10		1	5 units	41B
		3RT1.7 ³⁾						

¹⁾ Also fits on contactors of sizes S6 to S12 with box terminals.

²⁾ The 3RT1966-4EA3 cover is required in addition for use in reversing contactor assemblies and contactor assemblies for star-delta (wye-delta) starting.

³⁾ Exception: contactors and contactor relays with auxiliary switch block mounted onto the front.