

Motor Starter Protectors/Circuit Breakers

SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers

Accessories

Mounting accessories

Selection and ordering data

Accessories

Version	For motor starter protectors/circuit breakers	SD	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
	Size	d					
Covers							
 3RV2 (size S3) with 3RT1946-4EA1 (left)	Terminal covers For cable lug and busbar connection for maintaining the required voltage clearances and as touch protection if box terminal is removed (2 units can be mounted per motor starter protector/circuit breaker)	S3	5	3RT1946-4EA1	1	1 unit	41B
	Scale covers Sealable, for covering the set current scale	3RV20, 3RV21, 3RV24: S00 ... S3	▶	3RV2908-0P	100	10 units	41E
 3RV2908-0P	Covers for devices with screw terminals (box terminals) Additional touch protection to be fitted at the box terminals (2 units required per device)			Screw terminals 			
	• Main current level	S2	▶	3RT2936-4EA2	1	1 unit	41B
		S3	▶	3RT2946-4EA2	1	1 unit	41B
Fixing accessories							
 3RV2928-0B	Push-in lugs For screwing the motor starter protector/circuit breaker onto mounting plates Two units are required for each motor starter protector.	S00, S0	2	3RV2928-0B	100	10 units	41E
Tools for opening spring-type terminals							
 3RA2908-1A	Screwdrivers For all SIRIUS devices with spring-type terminals Length approx. 200 mm, 3.0 mm x 0.5 mm, titanium gray/black, partially insulated	S00 ... S3	2	Spring-type terminals  3RA2908-1A	1	1 unit	41B
Terminal covers for box terminals on 3RV2742 and Type E terminal block 3RT2946-4GA07							
 3RV2948-1LAA00	Additional touch protection to be fitted at the box terminals 3RV2742 (2 units required per device) and at Type E terminal block 3RT2946-4GA07 • Main current level	S3	NEW X	3RV2948-1LAA00	1	1 unit	41B